

PER/USE



PIANO

by Patrick Seha

Installation instructions

Parts (delivered)

- Piano hanger
- Side panels (2 – left and right)
- Wall mounting block (wood)

Needed (not included)

- Bolts/screws (3 or 4) best fit for the surface where the Piano will be installed

Installation

- 1 Fix the wall mounting block firmly with 3 bolts/screws for the Small version (or 4 for the Large version) to the wall where the Piano hanger will be installed.

*Make sure that the wall mounting block is perfectly horizontal;
The wall mounting block is positioned at 134,5 cm from the bottom side of the Piano (e.g. if you want the Piano to hang at 20 cm above the flooring, you fix the wall mounting block at 154,5 cm);
The wooden wall mounting block comes ready with 3 holes for the Small version (or 4 for the Large version) to insert countersunk head screws. If you would want to use larger bolts, you might have to enlarge the holes somewhat.*

- 2 Remove the two side panels of the hanger in case they come attached. Glide the Piano onto the wall mounting block. Make sure the Piano is centered at the middle of the block.
- 3 If you want to have the Piano keys to open less or more easily, simply adjust the screws at the different heights.
- 4 Place and plug the two side panels back onto the hanger.

